



Tool Name: TIMING GEAR COVER OIL SEAL REMOVER AND INSTALLER SET

Tool No: J 2776

Model Applications: 480 SERIES

Description:

J 2776 Remover and Installer is used in conjunction with J 872-5 Driver Handle as illustrated above.

The use of this tool permits removal and installation of the timing cover oil seal without damage to the seal or timing cover. The tool

head (B) is reversible on the handle. One side is used for removing, the other for replacing. The side with the tapered pilot is used for installing. When removing the seal, the cover is supported by the collar (A) which is notched to provide clearance for the bead inside the cover.